




Detalles del producto

## 8102

Conmutador Two-way switch for 1 rocker, LED exchangeable/ 10 A



### Información General

Tipo de producto extendido:	8102
Código de producto:	2CLA810200A1001
EAN:	8427238016429
Descripción corta:	Conmutador Two-way switch for 1 rocker, LED exchangeable/ 10 A

**Descripción larga:**

Elegante en cada uno de sus lados, lineal, equilibrada, esbelta... La serie Sky Niessen le da un aire moderno a cada uno de sus espacios. Su diseño minimalista facilita la integración en proyectos de arquitectura contemporánea, con una altura mínima sobre la pared. La tecla grande queda completamente integrada en el marco y el detalle cromado aporta un toque de elegante distinción. Tiene una gran gama de colores y acabados nobles que permiten adaptarnos a cualquier tipo de estancia. Es una serie ecodiseñada, por lo que los requisitos de sostenibilidad quedan garantizados.

La referencia 2CLA810200A1001 concretamente, se trata de un/a interruptor de la instalación.

Sus características son:

Tipo de montaje: Montado empotrado (escayola), Composición: Elemento básico, Tipo de operación: Balancín / botón, Método de conexión: Abrazadera de enchufe, Iluminación: Opcional, Tipo de iluminación: LED intercambiable, Tipo de fijación: Fijación mediante rosca, Tipo de circuito: Conmutador, Adecuado para el grado de protección (IP): IP20, Función de iluminación: Orientación, Voltaje nominal: 250V, Sin halógenos, Con placa de montaje, Corriente nominal (medida): 10A, Número de balancines: 1, Corriente de conmutación para lámparas fluorescentes: 10AX.

Fabricado en España

<b>Display Name:</b>	8102
----------------------	------

## Instalación

<b>Instrucciones y manuales:</b>	2CLX810109A1001
<b>Tipo de montaje:</b>	Montaje empotrado
<b>Tipo de fijación:</b>	Tornillo

## Ambiente

<b>Temperatura ambiente:</b>	Funcionamiento -5 ... +35 °C Almacenamiento -5 ... +50 °C
<b>Grado de protección:</b>	IP20

## Técnica

<b>Ficha técnica, información técnica:</b>	9AKK107046A0356
<b>Función:</b>	Función de iluminación: Orientación
<b>Número de interruptores basculantes:</b>	1
<b>Configuración del cableado:</b>	Two-way switch
<b>Tipo de actuador:</b>	Rocker/button
<b>Tipo de conexión:</b>	Abrazadera de tapón
<b>Tipo de lámpara:</b>	LED exchangeable
<b>Iluminación:</b>	Opcional
<b>Accesorios disponibles:</b>	Sí
<b>Número de pilas:</b>	0

## Eléctrica

<b>Tensión nominal (U<sub>r</sub>):</b>	250 V
<b>Corriente nominal (I<sub>n</sub>):</b>	10 A
<b>Corriente de conmutación máxima:</b>	Fluorescent Lamps 10

## Diseño

<b>Serie de mecanismos:</b>	Platform 8100 Alba Sky Niessen Alter Vega Vega Vega Estanco Arco
<b>Espacio para etiquetas:</b>	sin espacio para etiquetas

## Dimensiones

<b>Ancho del product:</b>	0.149 m
<b>Alto del producto:</b>	0.078 m
<b>Largo del product:</b>	0.225 m
<b>Peso del product:</b>	0.058 kg

## Clasificación

<b>ID de producto sustituido (ANTIGUO):</b>	2CL0810200
---	------------

## ABB EcoSolutions

<b>ABB EcoSolutions:</b>	Sí
--------------------------	----

## Valor Circular

**Tasa de reciclabilidad del producto según EN45555:** Diseño para cerrar ciclos de recursos - Norma EN45555 - 59 %

**Contenido de material sostenible en los envases (% en peso):** Cartón reciclado - 92 %

**Vida útil del producto prolongada:** Durabilidad del producto  
Modularidad del producto  
La extensión de la vida útil de los activos del cliente es posible gracias a la oferta y los servicios de apoyo

**Se ofrece con los servicios de recogida:** Devolución para reciclaje

**Declaración Ambiental de Producto - EPD:** 9AKK108468A8668

## Cumplimiento de Materiales

<b>Información sobre RoHS:</b>	2CLC00000008200
<b>Estado de RoHS:</b>	Siguiendo la Directiva de la UE 2011/65/UE y la Enmienda 2015/863 22 de julio de 2019
<b>Declaración REACH:</b>	2CLC00000003448
<b>Información REACH:</b>	Falso: no contiene sustancias > 0,1 porcentaje en masa
<b>Fecha REACH:</b>	20251231
<b>Plantilla de notificación de minerales de conflicto (CMRT):</b>	9AKK108468A3363
<b>Categoría RAEE:</b>	5. Equipo pequeño (sin dimensión externa de más de 50 cm)
<b>WEEE B2C / B2B:</b>	De empresa a consumidor

## Certificados y Declaraciones (Número de Documento)

**Declaración de conformidad - CE:** 9AKK106713A1744

**EU Data Act Applicability and Compliance:** Not Applicable

## Clasificaciones y estándares externos

**ETIM 9:** EC001590 - Installation switch

**ETIM 10:** EC001590 - Installation switch

**UNSPSC:** 39122226

## Accesorios

Identificador	Descripción	Cantidad	Tipo	Unidad de medida
ABB2CLA857110A1101	Marco basico 1 elemento -1 Blanco 1 ventana blanco - Sky Niessen		8571.1 BL	pieza
ABB2CLA857210A1101	Marco basico 2 elementos1 - Blanco 2 ventanas blanco - Sky Niessen		8572.1 BL	pieza
ABB2CLA857310A1101	Marco basico 3 elementos1 - Blanco 3 ventanas blanco - Sky Niessen		8573.1 BL	pieza
ABB2CLA857410A1101	Marco basico 4 elementos1 - Blanco 4 ventanas blanco - Sky Niessen		8574.1 BL	pieza
ABB2CLA857100A1101	Marco 1 elemento - Blanco1 1 ventana blanco - Sky Niessen		8571 BL	pieza
ABB2CLA857200A1101	Marco 2 elementos - 1 Blanco 2 ventanas blanco - Sky Niessen	1	8572 BL	pieza
ABB2CLA857300A1101	Marco 3 elementos - 1 Blanco 3 ventanas blanco - Sky Niessen	1	8573 BL	pieza
ABB2CLA857400A1101	Marco 4 elementos - 1 Blanco 4 ventanas blanco - Sky Niessen	1	8574 BL	pieza

ABB2CLA857100A1301	Marco 1 elemento- Plata 1 1 ventana plateado - Sky Niessen		8571 PL	pieza
ABB2CLA857200A1301	Marco 2 elementos- Plata 1 2 ventanas plateado - Sky Niessen		8572 PL	pieza
ABB2CLA857300A1301	Marco 3 elementos- Plata 1 3 ventanas plateado - Sky Niessen		8573 PL	pieza
ABB2CLA857400A1301	Marco 4 elementos- Plata 1 4 ventanas plateado - Sky Niessen		8574 PL	pieza
ABB2CLA857100A6201	Marco 1 elemento - Duna 11 ventana arena - Sky Niessen		8571 DN	pieza
ABB2CLA857200A6201	Marco 2 elementos - Duna 1 2 ventanas arena - Sky Niessen		8572 DN	pieza
ABB2CLA857300A6201	Marco 3 elementos - Duna 1 3 ventanas arena - Sky Niessen		8573 DN	pieza
ABB2CLA857400A6201	Marco 4 elementos - Duna 1 4 ventanas arena - Sky Niessen		8574 DN	pieza
ABB2CLA857100A6301	Marco 1 elemento - Taupé 1 1 ventana marrón - Sky Niessen		8571 TP	pieza
ABB2CLA857200A6301	Marco 2 elementos - 1 Taupé 2 ventanas marrón - Sky Niessen		8572 TP	pieza
ABB2CLA857300A6301	Marco 3 elementos - 1 Taupé 3 ventanas marrón - Sky Niessen		8573 TP	pieza
ABB2CLA857400A6301	Marco 4 elementos - 1 Taupé 4 ventanas marrón - Sky Niessen		8574 TP	pieza
ABB2CLA857100A1901	Marco 1 elemento - 1 Comodoro 1 ventana verde - Sky Niessen		8571 CM	pieza
ABB2CLA857200A1901	Marco 2 elementos - 1 Comodoro 2 ventanas verde - Sky Niessen		8572 CM	pieza
ABB2CLA857300A1901	Marco 3 elementos - 1 Comodoro 3 ventanas verde - Sky Niessen		8573 CM	pieza
ABB2CLA857400A1901	Marco 4 elementos - 1 Comodoro 4 ventanas verde - Sky Niessen		8574 CM	pieza
ABB2CLA857100A1501	Marco 1 elemento - Negro 1 Soft 1 ventana negro - Sky Niessen		8571 NS	pieza
ABB2CLA857200A1501	Marco 2 elementos - 1 Negro Soft 2 ventanas negro - Sky Niessen		8572 NS	pieza
ABB2CLA857300A1501	Marco 3 elementos - 1 Negro Soft 3 ventanas negro - Sky Niessen		8573 NS	pieza

ABB2CLA857400A1501	Marco 4 elementos - Negro Soft 4 ventanas negro - Sky Niessen	1	8574 NS	pieza
ABB2CLA857100A1401	Marco 1 elemento - Acero Inoxidable 1 ventana acero inoxidable - Sky Niessen	1	8571 AI	pieza
ABB2CLA857200A1401	Marco 2 elementos - Acero1 Inoxidable 2 ventanas acero inoxidable - Sky Niessen	1	8572 AI	pieza
ABB2CLA857300A1401	Marco 3 elementos - Acero1 Inoxidable 3 ventanas acero inoxidable - Sky Niessen	1	8573 AI	pieza
ABB2CLA857400A1401	Marco 4 elementos - Acero Inoxidable 4 ventanas acero inoxidable - Sky Niessen	1	8574 AI	pieza
ABB2CLA857100A1201	Marco 1 elemento - Oro Envejecido 1 ventana dorado - Sky Niessen	1	8571 OE	pieza
ABB2CLA857200A1201	Marco 2 elementos - Oro Envejecido 2 ventanas dorado - Sky Niessen	1	8572 OE	pieza
ABB2CLA857300A1201	Marco 3 elementos - Oro Envejecido 3 ventanas dorado - Sky Niessen	1	8573 OE	pieza
ABB2CLA857400A1201	Marco 4 elementos - Oro Envejecido 4 ventanas dorado - Sky Niessen	1	8574 OE	pieza
ABB2CLA857100A3001	Marco 1 elemento - Cristal Blanco 1 ventana blanco - Sky Niessen	1	8571 CB	pieza
ABB2CLA857200A3001	Marco 2 elementos - Cristal Blanco 2 ventanas blanco - Sky Niessen	1	8572 CB	pieza
ABB2CLA857300A3001	Marco 3 elementos - Cristal Blanco 3 ventanas blanco - Sky Niessen	1	8573 CB	pieza
ABB2CLA857400A3001	Marco 4 elementos - Cristal Blanco 4 ventanas blanco - Sky Niessen	1	8574 CB	pieza
ABB2CLA857100A3101	Marco 1 elemento - Cristal Negro 1 ventana negro - Sky Niessen	1	8571 CN	pieza
ABB2CLA857200A3101	Marco 2 elementos - Cristal Negro 2 ventanas negro - Sky Niessen	1	8572 CN	pieza
ABB2CLA857300A3101	Marco 3 elementos - Cristal Negro 3 ventanas negro - Sky Niessen	1	8573 CN	pieza
ABB2CLA857400A3101	Marco 4 elementos - Cristal Negro 4 ventanas negro - Sky Niessen	1	8574 CN	pieza
ABB2CLA857100A2001	Marco 1 elemento - Fresno1 1 ventana madera - Sky Niessen	1	8571 FR	pieza

ABB2CLA857200A2001	Marco 2 elementos - Fresno 2 ventanas madera - Sky Niessen	1	8572 FR	pieza
ABB2CLA857300A2001	Marco 3 elementos - Fresno 3 ventanas madera - Sky Niessen	1	8573 FR	pieza
ABB2CLA857400A2001	Marco 4 elementos - Fresno 4 ventanas madera - Sky Niessen	1	8574 FR	pieza
ABB2CLA857100A2101	Marco 1 elemento - Wengué 1 ventana madera - Sky Niessen	1	8571 WN	pieza
ABB2CLA857200A2101	Marco 2 elementos - Wengué 2 ventanas madera - Sky Niessen	1	8572 WN	pieza
ABB2CLA857300A2101	Marco 3 elementos - Wengué 3 ventanas madera - Sky Niessen	1	8573 WN	pieza
ABB2CLA857400A2101	Marco 4 elementos - Wengué 4 ventanas madera - Sky Niessen	1	8574 WN	pieza
ABB2CLA867100A4001	Frame 1-gang StainlessSteel - Skymoon	1	8671 OX	piece
ABB2CLA867200A4001	Frame 2-gang StainlessSteel - Skymoon	1	8672 OX	piece
ABB2CLA867300A4001	Frame 3-gang StainlessSteel - Skymoon	1	8673 OX	piece
ABB2CLA867100A3101	Frame 1-gang Black - Skymoon	1	8671 CN	piece
ABB2CLA867200A3101	Frame 2-gang Black - Skymoon	1	8672 CN	piece
ABB2CLA867300A3101	Frame 3-gang Black - Skymoon	1	8673 CN	piece
ABB2CLA867100A3001	Frame 1-gang White - Skymoon	1	8671 CB	piece
ABB2CLA867200A3001	Frame 2-gang White - Skymoon	1	8672 CB	piece
ABB2CLA867300A3001	Frame 3-gang White - Skymoon	1	8673 CB	piece
ABB2CLA847100A1001	Marco 1 elemento - Blanco jazmín 1 ventana blanco crema - Olas	1	8471 BL	pieza
ABB2CLA847200A1001	Marco 2 elementos vertical - Blanco jazmín 2 ventanas blanco crema - Olas	1	8472 BL	pieza
ABB2CLA847300A1001	Marco 3 elementos vertical - Blanco jazmín 3 ventanas blanco crema - Olas	1	8473 BL	pieza
ABB2CLA847400A1001	Marco 4 elementos vertical - Blanco jazmín 4 ventanas blanco crema - Olas	1	8474 BL	pieza
ABB2CLA847100A1701	Frame 1-gang Beige - Olas	1	8471 AR	piece
ABB2CLA847200A1701	Frame vertical 2-gang Beige - Olas	1	8472 AR	piece

ABB2CLA847300A1701	Frame vertical 3-gang Beige - Olas	1	8473 AR	piece
ABB2CLA847400A1701	Frame vertical 4-gang Beige - Olas	1	8474 AR	piece
ABB2CLA847100A1101	Frame 1-gang Bronze - Olas	1	8471 CS	piece
ABB2CLA847200A1101	Frame vertical 2-gang Bronze - Olas	1	8472 CS	piece
ABB2CLA847300A1101	Frame vertical 3-gang Bronze - Olas	1	8473 CS	piece
ABB2CLA847400A1101	Frame vertical 4-gang Bronze - Olas	1	8474 CS	piece
ABB2CLA847100A1401	Marco 1 elemento - Titanio 1 ventana titanio - Olas	1	8471 TT	pieza
ABB2CLA847200A1401	Marco 2 elementos vertical - Titanio 2 ventanas titanio - Olas	1	8472 TT	pieza
ABB2CLA847300A1401	Marco 3 elementos vertical - Titanio 3 ventanas titanio - Olas	1	8473 TT	pieza
ABB2CLA847400A1401	Marco 4 elementos vertical - Titanio 4 ventanas titanio - Olas	1	8474 TT	pieza
ABB2CLA847100A1201	Frame 1-gang Aluminium -1 Olas	1	8471 AL	piece
ABB2CLA847200A1201	Frame vertical 2-gang Aluminium - Olas	1	8472 AL	piece
ABB2CLA847300A1201	Frame vertical 3-gang Aluminium - Olas	1	8473 AL	piece
ABB2CLA847400A1201	Frame vertical 4-gang Aluminium - Olas	1	8474 AL	piece
ABB2CLA847100A1501	Frame 1-gang Aluminium -1 Olas	1	8471 AP	piece
ABB2CLA847200A1501	Frame vertical 2-gang Aluminium - Olas	1	8472 AP	piece
ABB2CLA847300A1501	Frame vertical 3-gang Aluminium - Olas	1	8473 AP	piece
ABB2CLA847400A1501	Frame vertical 4-gang Aluminium - Olas	1	8474 AP	piece
ABB2CLA827100A1101	Marco 1 elemento - Blanco1 Alpino 1 ventana blanco - Arco	1	8271 BA	pieza
ABB2CLA827200A1101	Marco 2 elementos - Blanco Alpino 2 ventanas blanco - Arco	1	8272 BA	pieza
ABB2CLA827300A1101	Marco 3 elementos - Blanco Alpino 3 ventanas blanco - Arco	1	8273 BA	pieza
ABB2CLA827400A1101	Marco 4 elementos - Blanco Alpino 4 ventanas blanco - Arco	1	8274 BA	pieza
ABB2CLA827100A1001	Frame 1-gang Ivory - Arco	1	8271 BM	piece
ABB2CLA827200A1001	Frame 2-gang Ivory - Arco	1	8272 BM	piece
ABB2CLA827300A1001	Frame 3-gang Ivory - Arco	1	8273 BM	piece

ABB2CLA827400A1001	Frame 4-gang Ivory - Arco	1	8274 BM	piece
ABB2CLA827110A1101	Marco 1 elemento - Blanco Alpino 1 ventana blanco - Arco		8271.1 BA	pieza
ABB2CLA827210A1101	Marco 2 elementos horizontal - Blanco Alpino 2 ventanas blanco - Arco	1	8272.1 BA	pieza
ABB2CLA827310A1101	Marco 3 elementos horizontal - Blanco Alpino 3 ventanas blanco - Arco	1	8273.1 BA	pieza
ABB2CLA827110A1001	Frame 1-gang Ivory - Arco	1	8271.1 BM	piece
2CLA480100A1501	Rocker switch - Vega Estanco	1	4801 NT	pieza
2CLA480100A1101	Rocker switch - Vega Estanco	1	4801 BL	pieza
2CLA480100A1001	Rocker switch - Vega Estanco	1	4801 BT	pieza
2CLA480130A1001	Rocker switch - Vega Estanco	1	4801.3 BT	pieza
2CLA480100A6201	Rocker switch - Vega Estanco	1	4801 DN	pieza
2CLA480130A6201	Rocker switch - Vega Estanco	1	4801.3 DN	pieza
2CLA480100A1601	Rocker switch - Vega Estanco	1	4801 GN	pieza
2CLA480130A1601	Rocker switch - Vega Estanco	1	4801.3 GN	pieza
2CLA550140A1101	Cover switch 0/l w/indicator Characters 0 and 1 for Switch/push button, Single rocker White - Tacto	1	5501.4 BL	piece
2CLA480130A1501	Rocker switch - Vega Estanco	1	4801.3 NT	pieza
2CLA550140A1301	Cover switch 0/l w/indicator Characters 0 and 1 for Switch/push button, Single rocker Silver - Tacto	1	5501.4 PL	piece
2CLA480130A1101	Rocker switch - Vega Estanco	1	4801.3 BL	pieza
2CLA550140A1801	Cover switch 0/l w/indicator Characters 0 and 1 for Switch/push button, Single rocker Anthracite - Tacto	1	5501.4 AN	piece
2CLA550140A1901	Cover switch 0/l w/indicator Characters 0 and 1 for Switch/push button, Single rocker Brass - Tacto	1	5501.4 CV	piece
2CLA550150A1101	Cover switch w/central indicator None for Switch/push button, Single rocker White - Tacto	1	5501.5 BL	piece

2CLA550150A1301	Cover switch w/central indicator None for Switch/push button, Single rocker Silver - Tacto	1	5501.5 PL	piece
2CLA550150A1801	Cover switch w/central indicator None for Switch/push button, Single rocker Anthracite - Tacto	1	5501.5 AN	piece
2CLA550150A1901	Cover switch w/central indicator None for Switch/push button, Single rocker Brass - Tacto	1	5501.5 CV	piece
2CLA550100A1101	Cover switch None for Switch/push button, Single rocker White - Tacto	1	5501 BL	piece
2CLA550100A1301	Cover switch None for Switch/push button, Single rocker Silver - Tacto	1	5501 PL	piece
2CLA550100A1801	Cover switch None for Switch/push button, Single rocker Anthracite - Tacto	1	5501 AN	piece
2CLA550100A1901	Cover switch None for Switch/push button, Single rocker Brass - Tacto	1	5501 CV	piece
2CLA550120A1101	Cover switch 0/I Characters 0 and 1 for Switch/push button, Single rocker White - Tacto	1	5501.2 BL	piece
2CLA550140A1103	5501.4 BL Cover switch 0/I w/indicator	1	5501.4 BL	piece
2CLA550120A1301	Cover switch 0/I Characters 0 and 1 for Switch/push button, Single rocker Silver - Tacto	1	5501.2 PL	piece
2CLA550140A1303	5501.4 TT Cover switch 0/I w/indicator	1	5501.4 TT	piece
2CLA550140A1803	5501.4 AN Cover switch 0/I w/indicator	1	5501.4 AN	piece
2CLA550120A1801	Cover switch 0/I Characters 0 and 1 for Switch/push button, Single rocker Anthracite - Tacto	1	5501.2 AN	piece
2CLA550140A1903	5501.4 CV Cover switch 0/I w/indicator	1	5501.4 CV	piece
2CLA550120A1901	Cover switch 0/I Characters 0 and 1 for Switch/push button, Single rocker Brass - Tacto	1	5501.2 CV	piece
2CLA550200A1166	Switch 2W Two-way switch with LED exchangeable White - Tacto	1	B5502 BL	piece

2CLA550130A1101	Cover switch w/indicator 1 None for Switch/push button, Single rocker White - Tacto		5501.3 BL	piece
2CLA550200A1366	Switch 2W Two-way switch with LED exchangeable Silver - Tacto	1	B5502 PL	piece
2CLA550200A1966	Switch 2W Two-way switch with LED exchangeable Brass - Tacto	1	B5502 CV	piece
2CLA550130A1301	Cover switch w/indicator 1 None for Switch/push button, Single rocker Silver - Tacto		5501.3 PL	piece
2CLA550100A1103	5501 BL Cover switch	1	5501 BL	piece
2CLA550100A1303	5501 TT Cover switch	1	5501 TT	piece
2CLA550100A1803	5501 AN Cover switch	1	5501 AN	piece
2CLA550100A1903	5501 CV Cover switch	1	5501 CV	piece
2CLA550130A1103	5501.3 BL Cover switch w/indicator	1	5501.3 BL	piece
2CLA550130A1801	Cover switch w/indicator 1 None for Switch/push button, Single rocker Anthracite - Tacto		5501.3 AN	piece
2CLA550130A1901	Cover switch w/indicator 1 None for Switch/push button, Single rocker Brass - Tacto		5501.3 CV	piece
2CLA550130A1303	5501.3 TT Cover switch w/indicator	1	5501.3 TT	piece
2CLA550130A1803	5501.3 AN Cover switch w/indicator	1	5501.3 AN	piece
2CLA550130A1903	5501.3 CV Cover switch w/indicator	1	5501.3 CV	piece
2CLA820100A1001	Rocker switch Without imprint for Switch/push button, Single rocker Ivory - Arco	1	8201 BM	piece
2CLA820100A1101	Tecla sin visor - Blanco Alpino Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Arco	1	8201 BA	pieza
2CLA820120A1001	Rocker switch Characters 1 0 and 1 for Switch/push button, Single rocker Ivory - Arco		8201.2 BM	piece
2CLA820120A1101	Tecla on - off sin visor - Blanco Alpino Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Arco	1	8201.2 BA	pieza
2CLA820100A1003	8201 BM Cover switch	1	8201 BM	piece
2CLA820100A1103	8201 BA Cover switch	1	8201 BA	piece

2CLA820120A1003	8201.2 BM Cover switch 0/I	1	8201.2 BM	piece
2CLA820120A1103	8201.2 BA Cover switch 0/I	1	8201.2 BA	piece
2CLA820130A1001	Rocker switch Without imprint for Switch/push button, Single rocker Ivory - Arco	1	8201.3 BM	piece
2CLA820130A1101	Tecla con visor - Blanco Alpino Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Arco	1	8201.3 BA	pieza
2CLA820140A1001	Rocker switch Characters 0 and 1 for Switch/push button, Single rocker Ivory - Arco	1	8201.4 BM	piece
2CLA820140A1101	Tecla on - off con visor - Blanco Alpino Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Arco	1	8201.4 BA	pieza
2CLA820130A1003	8201.3 BM Cover switch w/indicator	1	8201.3 BM	piece
2CLA820130A1103	8201.3 BA Cover switch w/indicator	1	8201.3 BA	piece
2CLA820140A1003	8201.4 BM Cover switch 0/I w/indicator	1	8201.4 BM	piece
2CLA820140A1103	8201.4 BA Cover switch 0/I w/indicator	1	8201.4 BA	piece
2CLA820190A1001	Rocker switch Without imprint for Switch/push button, Single rocker Ivory - Arco	1	8201.9 BM	piece
2CLA820190A1101	Tecla interruptor con Rótulo - Blanco Alpino Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Arco	1	8201.9 BA	pieza
2CLA840120A1201	Cover switch 0/I Characters 0 and 1 for Switch/push button, Single rocker Aluminium - Olas	1	8401.2 AL	piece
2CLA840130A1001	Tecla con visor - Blanco jazmín Sin símbolo for Interruptor/pulsador, Tecla individual blanco crema - Olas	1	8401.3 BL	pieza
2CLA840130A1101	Rocker switch Without imprint for Switch/push button, Single rocker Bronze - Olas	1	8401.3 CS	piece
2CLA840130A1401	Tecla con visor- Titanio Sin símbolo for Interruptor/pulsador, Tecla individual titanio - Olas	1	8401.3 TT	pieza

2CLA840130A1201	Cover switch w/indicator 1 Without imprint for Switch/push button, Single rocker Aluminium - Olas		8401.3 AL	piece
2CLA840130A1501	Cover switch w/indicator 1 Without imprint for Switch/push button, Single rocker Aluminium - Olas		8401.3 AP	piece
2CLA840130A1701	Cover switch w/indicator 1 Without imprint for Switch/push button, Single rocker Beige - Olas		8401.3 AR	piece
2CLA840140A1001	Tecla on - off con visor - 1 Blanco jazmín Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco crema - Olas		8401.4 BL	pieza
2CLA840140A1101	Rocker switch Characters 1 0 and 1 for Switch/push button, Single rocker Bronze - Olas		8401.4 CS	piece
2CLA840140A1401	Tecla on - off con visor 1 Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual titanio - Olas		8401.4 TT	pieza
2CLA840140A1501	Cover switch 0/l 1 w/indicator Characters 0 and 1 for Switch/push button, Single rocker Aluminium - Olas		8401.4 AP	piece
2CLA840100A1001	Tecla sin visor - Blanco 1 jazmín Sin símbolo for Interruptor/pulsador, Tecla individual blanco crema - Olas		8401 BL	pieza
2CLA840140A1701	Cover switch 0/l 1 w/indicator Characters 0 and 1 for Switch/push button, Single rocker Beige - Olas		8401.4 AR	piece
2CLA840100A1101	Rocker switch Without 1 imprint for Switch/push button, Single rocker Bronze - Olas		8401 CS	piece
2CLA840100A1401	Tecla sin visor- Titanio Sin 1 símbolo for Interruptor/pulsador, Tecla individual titanio - Olas		8401 TT	pieza
2CLA840140A1201	Cover switch 0/l 1 w/indicator Characters 0 and 1 for Switch/push button, Single rocker Aluminium - Olas		8401.4 AL	piece
2CLA840100A1501	Cover switch Without 1 imprint for Switch/push button, Single rocker Aluminium - Olas		8401 AP	piece

2CLA840100A1701	Cover switch Without imprint for Switch/push button, Single rocker Beige - Olas	1	8401 AR	piece
2CLA840100A1201	Cover switch Without imprint for Switch/push button, Single rocker Aluminium - Olas	1	8401 AL	piece
2CLA840120A1001	Tecla on - off sin visor - Blanco jazmín Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco crema - Olas	1	8401.2 BL	pieza
2CLA840120A1101	Rocker switch Characters 0 and 1 for Switch/push button, Single rocker Bronze - Olas	1	8401.2 CS	piece
2CLA840120A1401	Tecla on - off sin visor- Titanio Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual titanio - Olas	1	8401.2 TT	pieza
2CLA840120A1501	Cover switch 0/1 Characters 0 and 1 for Switch/push button, Single rocker Aluminium - Olas	1	8401.2 AP	piece
2CLA840120A1701	Cover switch 0/1 Characters 0 and 1 for Switch/push button, Single rocker Beige - Olas	1	8401.2 AR	piece
2CLA840200A1066	Conmutador Olas - Blanco1 jazmín Two-way switch with LED exchangeable blanco crema - Olas	1	B8402 BL	pieza
2CLA840200A1166	Conmutador Olas - Cobre Satén Two-way switch with LED exchangeable bronce - Olas	1	B8402 CS	pieza
2CLA840200A1466	Conmutador Olas - Titanio Two-way switch with LED exchangeable titanio - Olas	1	B8402 TT	pieza
2CLA840200A1566	B8402 AP Rocker switch 2W	1	B8402 AP	piece
2CLA840200A1766	Rocker switch 2W Two-way switch with LED exchangeable Beige - Olas	1	B8402 AR	piece
2CLA840200A1266	Rocker switch 2W Two-way switch with LED exchangeable Aluminium - Olas	1	B8402 AL	piece
2CLA850100A1101	Tecla interruptor-conmutador - Blanco Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Sky Niessen	1	8501 BL	pieza

2CLA850100A1301	Tecla interruptor- conmutador- Plata Sin símbolo for Interruptor/pulsador, Tecla individual plateado - Sky Niessen	1	8501 PL	pieza
2CLA850100A1401	Tecla interruptor- conmutador - Acero Inoxidable Sin símbolo for Interruptor/pulsador, Tecla individual acero inoxidable - Sky Niessen	1	8501 AI	pieza
2CLA850100A1501	Tecla interruptor- conmutador - Negro Soft Sin símbolo for Interruptor/pulsador, Tecla individual negro - Sky Niessen	1	8501 NS	pieza
2CLA850130A2501	Tecla interruptor c/visor - 1 Cristal Negro Sin símbolo for Interruptor/pulsador, Tecla individual negro - Sky Niessen	1	8501.3 CN	pieza
2CLA850100A2101	Tecla interruptor- conmutador - Cristal Blanco Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Sky Niessen	1	8501 CB	pieza
2CLA850140A1101	Tecla interruptor bip. c/visor - Blanco Caracteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Sky Niessen	1	8501.4 BL	pieza
2CLA850140A1301	Tecla interruptor bip. c/visor- Plata Caracteres 0 y 1 for Interruptor/pulsador, Tecla individual plateado - Sky Niessen	1	8501.4 PL	pieza
2CLA850100A2501	Tecla interruptor- conmutador - Cristal Negro Sin símbolo for Interruptor/pulsador, Tecla individual negro - Sky Niessen	1	8501 CN	pieza
2CLA850120A1101	Tecla interruptor bipolar - 1 Blanco Caracteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Sky Niessen	1	8501.2 BL	pieza
2CLA850140A1401	Tecla interruptor bip. c/visor - Acero Inoxidable Caracteres 0 y 1 for Interruptor/pulsador, Tecla individual acero inoxidable - Sky Niessen	1	8501.4 AI	pieza
2CLA850120A1301	Tecla interruptor bipolar- 1 Plata Caracteres 0 y 1 for Interruptor/pulsador, Tecla individual plateado - Sky Niessen	1	8501.2 PL	pieza

2CLA850120A1501	Tecla interruptor bipolar - 1 Negro Soft Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual negro - Sky Niessen		8501.2 NS	pieza
2CLA850100A1601	8501 NSD Rocker for switches	1	8501 NSD	piece
2CLA850100A1201	Tecla interruptor-conmutador - Oro Envejecido Sin símbolo for Interruptor/pulsador, Tecla individual dorado - Sky Niessen	1	8501 OE	pieza
2CLA850130A1101	Tecla interruptor c/visor - 1 Blanco Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Sky Niessen		8501.3 BL	pieza
2CLA850130A1301	Tecla interruptor c/visor- 1 Plata Sin símbolo for Interruptor/pulsador, Tecla individual plateado - Sky Niessen		8501.3 PL	pieza
2CLA850120A1201	Tecla interruptor bipolar - 1 Oro Envejecido Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual dorado - Sky Niessen		8501.2 OE	pieza
2CLA850130A1401	Tecla interruptor c/visor - 1 Acero Inoxidable Sin símbolo for Interruptor/pulsador, Tecla individual acero inoxidable - Sky Niessen		8501.3 AI	pieza
2CLA850100A1901	Tecla interruptor-conmutador - Comodoro Sin símbolo for Interruptor/pulsador, Tecla individual verde - Sky Niessen	1	8501 CM	pieza
2CLA850130A1501	Tecla interruptor c/visor - 1 Negro Soft Sin símbolo for Interruptor/pulsador, Tecla individual negro - Sky Niessen		8501.3 NS	pieza
2CLA850130A2101	Tecla interruptor c/visor - 1 Cristal Blanco Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Sky Niessen		8501.3 CB	pieza
2CLA850120A1401	Tecla interruptor bipolar - 1 Acero Inoxidable Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual acero inoxidable - Sky Niessen		8501.2 AI	pieza
2CLA850100A6201	Tecla interruptor-conmutador - Duna Sin símbolo for Interruptor/pulsador, Tecla individual duna - Sky Niessen	1	8501 DN	pieza

2CLA850140A1501	Tecla interruptor bip. c/visor - Negro Soft Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual negro - Sky Niessen	1	8501.4 NS	pieza
2CLA850130A1201	Tecla interruptor c/visor - 1 Oro Envejecido Sin símbolo for Interruptor/pulsador, Tecla individual dorado - Sky Niessen	1	8501.3 OE	pieza
2CLA850100A6301	Tecla interruptor-conmutador - Taupé Sin símbolo for Interruptor/pulsador, Tecla individual marrón - Sky Niessen	1	8501 TP	pieza
2CLA850140A1201	Tecla interruptor bip. c/visor - Oro Envejecido Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual dorado - Sky Niessen	1	8501.4 OE	pieza
2CLA850100A4101	Rocker switch Without imprint for Switch/push button, Single rocker White - Sky Niessen	1	8501 BB	piece
2CLA850140A1901	Tecla interruptor bip. c/visor - Comodoro Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual verde - Sky Niessen	1	8501.4 CM	pieza
2CLA850120A1901	Tecla interruptor bipolar - 1 Comodoro Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual verde - Sky Niessen	1	8501.2 CM	pieza
2CLA850130A1901	Tecla interruptor c/visor - 1 Comodoro Sin símbolo for Interruptor/pulsador, Tecla individual verde - Sky Niessen	1	8501.3 CM	pieza
2CLA850130A6301	Tecla interruptor c/visor - 1 Taupé Sin símbolo for Interruptor/pulsador, Tecla individual marrón - Sky Niessen	1	8501.3 TP	pieza
2CLA850120A6301	Tecla interruptor bipolar - 1 Taupé Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual marrón - Sky Niessen	1	8501.2 TP	pieza
2CLA850120A6201	Tecla interruptor bipolar - 1 Duna Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual duna - Sky Niessen	1	8501.2 DN	pieza

2CLA850130A6201	Tecla interruptor c/visor - 1 Duna Sin símbolo for Interruptor/pulsador, Tecla individual duna - Sky Niessen		8501.3 DN	pieza
2CLA850120A4101	Rocker switch Characters 1 0 and 1 for Switch/push button, Single rocker White - Sky Niessen		8501.2 BB	piece
2CLA850130A4101	Rocker switch Without 1 imprint for Switch/push button, Single rocker White - Sky Niessen		8501.3 BB	piece
2CLA850140A6201	Tecla interruptor bip. 1 c/visor - Duna Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual duna - Sky Niessen		8501.4 DN	pieza
2CLA850140A6301	Tecla interruptor bip. 1 c/visor - Taupé Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual marrón - Sky Niessen		8501.4 TP	pieza
2CLA850140A4101	Rocker switch Characters 1 0 and 1 for Switch/push button, Single rocker White - Sky Niessen		8501.4 BB	piece
2CLA860100A1401	Rocker Without imprint 1 for Switch/push button, Single rocker Chrome - Skymoon		8601 CR	piece
2CLA860100A1501	Rocker Without imprint 1 for Switch/push button, Single rocker Black - Skymoon		8601 CN	piece
2CLA860130A1401	Rocker Without imprint 1 for Switch/push button, Single rocker Chrome - Skymoon		8601.3 CR	piece
2CLA860130A1501	Rocker Without imprint 1 for Switch/push button, Single rocker Black - Skymoon		8601.3 CN	piece
2CLA870100A1101	Tecla interruptor- 1 conmutador Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Arco		8701 BA	pieza
2CLA870120A1101	Tecla interruptor bipolar 1 Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Arco		8701.2 BA	pieza
2CLA870130A1101	Tecla interruptor c/visor 1 Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Arco		8701.3 BA	pieza

2CLA870140A1101	Tecla interruptor bip. c/visor Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Arco	1	8701.4 BA	pieza
2CLA866020A1401	Cover plate Without imprint for Dimmer Turn button Chrome - Skymoon	1	8660.2 CR	piece
2CLA866020A1501	Cover plate Without imprint for Dimmer Turn button Black - Skymoon	1	8660.2 CN	piece
2CLA880100A1501	Tecla None for Switch/push button, One-part rocker negro - Vega	1	8801 NT	pieza
2CLA880100A7201	Rocker None for Switch/push button, One-part rocker Niquel - Vega	1	8801 NZ	piece
2CLA880100A7101	Rocker None for Switch/push button, One-part rocker Stainless steel - Vega	1	8801 AZ	piece
2CLA880108A1001	Tecla None for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.08 BT	pieza
2CLA880100A1601	Tecla None for Switch/push button, One-part rocker gris - Vega	1	8801 GN	pieza
2CLA880100A6201	Tecla None for Switch/push button, One-part rocker duna - Vega	1	8801 DN	pieza
2CLA880100A7301	Rocker None for Switch/push button, One-part rocker Black - Vega	1	8801 CZ	piece
2CLA880100A1101	Tecla None for Switch/push button, One-part rocker blanco - Vega	1	8801 BL	pieza
2CLA880100A1001	Tecla None for Switch/push button, One-part rocker blanco - Vega	1	8801 BT	pieza
2CLA866020A1466	Cover dimmer Chrome - Skymoon	1	B8660.2 CR	piece
2CLA866020A1566	Cover dimmer Black - Skymoon	1	B8660.2 CN	piece
2CLA880128A1501	Tecla Characters 0 and 1 for Switch/push button, One-part rocker negro - Alter Vega	1	8801.28 NT	pieza
2CLA880130A1101	Tecla None for Switch/push button, One-part rocker blanco - Vega	1	8801.3 BL	pieza
2CLA880120A7101	Rocker Characters 0 and 1 for Switch/push button, One-part rocker Stainless steel - Vega	1	8801.2 AZ	piece
2CLA880120A7201	Rocker Characters 0 and 1 for Switch/push button, One-part rocker Niquel - Vega	1	8801.2 NZ	piece

2CLA880120A7301	Rocker Characters 0 and 1 for Switch/push button, One-part rocker Black - Vega		8801.2 CZ	piece
2CLA880128A1601	Tecla Characters 0 and 1 for Switch/push button, One-part rocker gris - Alter Vega	1	8801.28 GN	pieza
2CLA880108A1501	Tecla None for Switch/push button, One-part rocker negro - Alter Vega	1	8801.08 NT	pieza
2CLA880120A6201	Tecla Characters 0 and 1 for Switch/push button, One-part rocker duna - Vega	1	8801.2 DN	pieza
2CLA880128A1101	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.28 BL	pieza
2CLA880130A1501	Tecla None for Switch/push button, One-part rocker negro - Vega	1	8801.3 NT	pieza
2CLA880128A1001	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.28 BT	pieza
2CLA880120A1501	Tecla Characters 0 and 1 for Switch/push button, One-part rocker negro - Vega	1	8801.2 NT	pieza
2CLA880130A1601	Tecla None for Switch/push button, One-part rocker gris - Vega	1	8801.3 GN	pieza
2CLA880120A1601	Tecla Characters 0 and 1 for Switch/push button, One-part rocker gris - Vega	1	8801.2 GN	pieza
2CLA880108A1101	Tecla None for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.08 BL	pieza
2CLA880108A7301	Rocker None for Switch/push button, One-part rocker Black - Vega	1	8801.08 CZ	piece
2CLA880140A6201	Tecla Characters 0 and 1 for Switch/push button, One-part rocker duna - Vega	1	8801.4 DN	pieza
2CLA880120A1001	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Vega	1	8801.2 BT	pieza
2CLA880108A6201	Tecla None for Switch/push button, One-part rocker duna - Alter Vega	1	8801.08 DN	pieza
2CLA880120A1101	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Vega	1	8801.2 BL	pieza

2CLA880148A7101	Rocker Characters 0 and 11 for Switch/push button, One-part rocker Stainless steel - Alter Vega		8801.48 AZ	piece
2CLA880108A1601	Tecla None for Switch/push button, One-part rocker gris - Alter Vega	1	8801.08 GN	pieza
2CLA880128A7201	Rocker Characters 0 and 11 for Switch/push button, One-part rocker Niquel - Alter Vega		8801.28 NZ	piece
2CLA880148A7201	Rocker Characters 0 and 11 for Switch/push button, One-part rocker Niquel - Alter Vega		8801.48 NZ	piece
2CLA880128A7101	Rocker Characters 0 and 11 for Switch/push button, One-part rocker Stainless steel - Alter Vega		8801.28 AZ	piece
2CLA880138A1001	Tecla None for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.38 BT	pieza
2CLA880108A7101	Rocker None for Switch/push button, One-part rocker Stainless steel - Alter Vega	1	8801.08 AZ	piece
2CLA880128A6201	Tecla Characters 0 and 1 for Switch/push button, One-part rocker duna - Alter Vega	1	8801.28 DN	pieza
2CLA880140A7301	Rocker Characters 0 and 11 for Switch/push button, One-part rocker Black - Vega		8801.4 CZ	piece
2CLA880128A7301	Rocker Characters 0 and 11 for Switch/push button, One-part rocker Black - Vega		8801.28 CZ	piece
2CLA880108A7201	Rocker None for Switch/push button, One-part rocker Niquel - Alter Vega	1	8801.08 NZ	piece
2CLA880148A1601	Tecla Characters 0 and 1 for Switch/push button, One-part rocker gris - Alter Vega	1	8801.48 GN	pieza
2CLA880130A1001	Tecla None for Switch/push button, One-part rocker blanco - Vega	1	8801.3 BT	pieza
2CLA880148A1501	Tecla Characters 0 and 1 for Switch/push button, One-part rocker negro - Alter Vega	1	8801.48 NT	pieza
2CLA880140A1601	Tecla Characters 0 and 1 for Switch/push button, One-part rocker gris - Vega	1	8801.4 GN	pieza


2CLA880140A7201	Rocker Characters 0 and 1 for Switch/push button, One-part rocker Niquel - Vega		8801.4 NZ	piece
2CLA880138A1101	Tecla None for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.38 BL	pieza
2CLA880130A7101	Rocker None for Switch/push button, One-part rocker Stainless steel - Vega	1	8801.3 AZ	piece
2CLA880140A7101	Rocker Characters 0 and 1 for Switch/push button, One-part rocker Stainless steel - Vega		8801.4 AZ	piece
2CLA880148A1001	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.48 BT	pieza
2CLA880130A7201	Rocker None for Switch/push button, One-part rocker Niquel - Vega	1	8801.3 NZ	piece
2CLA880148A1101	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Alter Vega	1	8801.48 BL	pieza
2CLA880130A7301	Rocker None for Switch/push button, One-part rocker Black - Vega	1	8801.3 CZ	piece
2CLA880138A7101	Rocker None for Switch/push button, One-part rocker Stainless steel - Alter Vega	1	8801.38 AZ	piece
2CLA880140A1501	Tecla Characters 0 and 1 for Switch/push button, One-part rocker negro - Vega	1	8801.4 NT	pieza
2CLA880130A6201	Tecla None for Switch/push button, One-part rocker duna - Vega	1	8801.3 DN	pieza
2CLA880138A1501	Tecla None for Switch/push button, One-part rocker negro - Alter Vega	1	8801.38 NT	pieza
2CLA880138A1601	Tecla None for Switch/push button, One-part rocker gris - Alter Vega	1	8801.38 GN	pieza
2CLA880138A6201	Tecla None for Switch/push button, One-part rocker duna - Alter Vega	1	8801.38 DN	pieza
2CLA880148A7301	Rocker Characters 0 and 1 for Switch/push button, One-part rocker Black - Vega		8801.48 CZ	piece
2CLA880140A1101	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Vega	1	8801.4 BL	pieza

2CLA880138A7201	Rocker None for Switch/push button, One-part rocker Niquel - Alter Vega	1	8801.38 NZ	piece
2CLA880138A7301	Rocker None for Switch/push button, One-part rocker Black - Vega	1	8801.38 CZ	piece
2CLA880140A1001	Tecla Characters 0 and 1 for Switch/push button, One-part rocker blanco - Vega	1	8801.4 BT	pieza
2CLA880148A6201	Tecla Characters 0 and 1 for Switch/push button, One-part rocker duna - Alter Vega	1	8801.48 DN	pieza
2CLA890100A1001	Tecla Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901 BT	pieza
2CLA890100A1501	Tecla interruptor-conmutador NT Sin símbolo for Interruptor/pulsador, Tecla individual negro - Alba	1	8901 NT	pieza
2CLA890100A1101	Tecla interruptor-conmutador BL Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901 BL	pieza
2CLA890130A1501	Tecla Sin símbolo for Interruptor/pulsador, Tecla individual negro - Alba	1	8901.3 NT	pieza
2CLA890120A1101	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901.2 BL	pieza
2CLA890120A1501	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual negro - Alba	1	8901.2 NT	pieza
2CLA890120A1001	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901.2 BT	pieza
2CLA890130A1001	Tecla Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901.3 BT	pieza
2CLA890120A1801	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual gris - Alba	1	8901.2 GR	pieza
2CLA890100A1801	Tecla Sin símbolo for Interruptor/pulsador, Tecla individual gris - Alba	1	8901 GR	pieza
2CLA890109A1001	Rocker None for Switch/push button, One-part rocker blanco - Alba Infinity	1	8901.09 BT	pieza

2CLA890109A1101	Rocker None for Switch/push button, One-part rocker blanco - Alba Infinity	1	8901.09 BL	pieza
2CLA890130A1801	Tecla Sin símbolo for Interruptor/pulsador, Tecla individual gris - Alba	1	8901.3 GR	pieza
2CLA890109A1801	Rocker None for Switch/push button, One-part rocker gris - Alba Infinity	1	8901.09 GR	pieza
2CLA890109A1501	Rocker None for Switch/push button, One-part rocker negro - Alba Infinity	1	8901.09 NT	pieza
2CLA890140A1801	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual gris - Alba	1	8901.4 GR	pieza
2CLA890140A1001	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901.4 BT	pieza
2CLA890140A1501	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual negro - Alba	1	8901.4 NT	pieza
2CLA890140A1101	Tecla Carácteres 0 y 1 for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901.4 BL	pieza
2CLA890130A1101	Tecla Sin símbolo for Interruptor/pulsador, Tecla individual blanco - Alba	1	8901.3 BL	pieza
2CLA890139A1501	Rocker None for Switch/push button, One-part rocker negro - Alba Infinity	1	8901.39 NT	pieza
2CLA890139A1101	Rocker None for Switch/push button, One-part rocker blanco - Alba Infinity	1	8901.39 BL	pieza
2CLA890139A1001	Rocker None for Switch/push button, One-part rocker blanco - Alba Infinity	1	8901.39 BT	pieza
2CLA890139A1801	Rocker None for Switch/push button, One-part rocker gris - Alba Infinity	1	8901.39 GR	pieza

## Categorías

Productos > Productos y sistemas de baja tensión > Series de mecanismos > Mecanismos > Funciones mecánicas



360°